
#### Common part


- Simple RC and CR networks
- Signal propagation
- Operational Amplifiers
  - Non-inverting
  - Inverting
- Triangle generator with Schmitt trigger and Integrator
- Discriminator with comparator


#### The breadboard





Investigate simple RC and CR networks measure the


- Attenuation and phase shift at 1Hz, 10Hz, ...100kHz, 1MHz with sinus input signal
- Rise/fall time using 1Hz rectangular input signal
- Identify low pass and high pass filter
- Construct a bandpass filter from both











#### Signal propagation


Investigate a piece of coaxial cable (50 $\Omega$ )

- With the cable from the generator to the oscilloscope and
  - with  $50\Omega$  termination
  - with other termination
  - without termination


measure the waveform

- with the shortest rise/fall time
- with longer rise/fall time


and try to explain the results




### Signal propagation (2)



### Signal propagation (3)



### Signal propagation (4)




#### Signal propagation (5)


Investigate two pieces of coaxial cable (50 $\Omega$ )

- With two cables as shown below and
  - with  $50\Omega$  termination
  - with other termination
  - without termination
  - with short


at the far end of the second cable measure the waveforms and try to explain the results




## Signal propagation (6)



## Signal propagation (7)




### Signal propagation (8)




#### Signal propagation - conclusions

- The fastest component of a signal is its rise/fall time T<sub>R</sub>
- The characteristic time of a piece of cable is the transit time
   T<sub>T</sub>, for typical coaxial cable about 5 ns/m
- If T<sub>R</sub> >> T<sub>T</sub>, the signal is slow and probably the only trouble could arise from the *cable capacitance* (typically around 100 pF/m)
- For fast signals a proper termination corresponding to its characteristic impedance is necessary, to avoid signal degradation



#### **Operational Amplifiers**

- Ideal and real voltage feedback amplifier (VFA) parameter
- Negative feedback with VFA
  - Non-inverting amplifier offset, bandwidth, slew rate
- Positive feedback
  - Schmidt trigger, oscillator
  - Discriminator



Standard Pin-out of single and dual OA in a 8-pin package (DIL-8 or SOIC-8)

#### Operational Amplifiers in Simulator

LTspice comes with models from Linear Technology. In order to simulate an Op Amp from other manufacturer:


- Using google or a search on the manufacturer web page find a spice simulation model of the Op Amp – this must be a text file – check this with an text editor!
- Instantiate opamp2 from the [Opamps] directory
- In symbol properties change the line with value containing opamp2 with the name of the file containing the model, e.g. TL071.lib
- In the schematic sheet add a spice directive with .op like
   .inc TL071.lib or .lib TL071.lib
- Copy the file with the simulation model in the project directory with the proper name (here TL071.lib)

#### Non-inverting amplifier

For gain=1, ≈10, ≈100

- Calculate the resistors R1, R2
- Measure the offset voltage (only at Gain ≈100)
- Estimate the input bias current

#### measure the




- Output impedance combine with the previous measurement + measure the output amplitude with proper load (e.g. 1k)
- Rise/Fall time, slew rate and settling time to 1% of the step using 1Hz rectangular input signal and output amplitude 5% and 90% of the full range; repeat the measurements with 100pF capacitive load at the output


$$K_{\beta} = \frac{U_{OUT}}{U_{IN}} \approx 1 + \frac{R_2}{R_1} = \frac{1}{\beta} \ge 1$$

R2

#### **Definitions**




#### Non-inverting amplifier



#### Inverting amplifier


For gain=-1, -10, -100

 Calculate the resistors R1, R2 measure the




• Gain at 1Hz, 1kHz, 100kHz, 1MHz with small signal sinus (output amplitude = 5% of the full range at 1 Hz) and if possible with large signal sinus (output amplitude = 90% of the full range at 1Hz)

- The signal at the "virtual ground" the negative input of the OA
  while measuring the Gain and again with rectangular input signal
  and output amplitude about 90% of the full range Influence of the osc-probe?
- For Gain=10 add a capacitor in the feedback so, that the bandwidth is limited to 10kHz; measure the Gain at 1Hz, 1kHz, 10kHz, 100kHz using sinus input signal; measure the rise/fall time using rectangular input signal



# Triangle generator using comparator and integrator


#### **OPTIONAL!**



- Select the values of R1, R2, R and C in order to get frequency about 1 kHz and output range -10..+10V
- How can be varied only the frequency of the output signal?
- How can be varied only the amplitude of the output signal?

Use OPA2227 or OPA2277 or TL082

#### Comparator




AD8561, LT1016

Warning, the pin-out is NOT so standardized as for the operational amplifier!

In Simulator: if the model is missing, find it in internet (text file!), open the text file in LTspice, go to the line with .SUBCKT, then right-click and select **Create symbol**. It is recommended then to edit the symbol, at least to set the proper pin-names. The symbol contains as attribute the absolute location of the model in the file system => remove the absolute path prefix. The generated symbol is by default saved in [AutoGenerated] sub-directory of the lib\sym\ directory of LTspice: ver. XVII in ...\MyDocs\LTspiceXVII\, ver. IV in C:\Program Files (x86)\LTC\LTspiceIV\

#### Discriminator – basic idea



Preferably use a true comparator instead of Op Ampl in this experiment Investigate the discriminator

- Vary the amplitude and the rise/fall times of the input signal
- Add some high frequency noise to the input signal using a second generator and capacitive coupling
- Adjust the hysteresis according to the noise level
- Measure the input to output delay at different input amplitudes
   Applications:
- Single Channel Analyser (SCA)
- Time Over Threshold Analyzer
- Timing


#### Specific part

- Particle physics experiments
  - Shaping Amplifier and Pole/Zero correction
  - Single channel analyser (SCA)
  - Time over Threshold (ToT)
  - Timing with Leading Edge (LE) and Constant Fraction Discriminators (CFD)
- Optical experiments
  - Constant current sources
  - Temperature measurements
  - Photodiode amplifier
  - PID

#### **Shaping Amplifier**

- The preamplifier delivers normally long exponential pulses, which may overlap
- The later amplifier stages have several functions:
  - Invert the polarity if necessary
  - Shorten the pulses with fast return to zero
  - Amplify to a level proper for further processing
  - Shape optimal for the signal to noise ratio and for the further processing (digitization)
- Simulate and build a shaping amplifier, play with the P/Z correction and the shaping parameters (shaping time, gain), vary the delay between the two pulses to see the effect of overlapping


#### Shaping Amplifier



Possible OpAmp: LT1361 (slowest), LT1364, LM6172 (fastest)

#### Single Channel Analyzer

Select pulses with amplitude in some programmable window




- Use two discriminators for the upper level (UL) and lower level (LL)
- Some logic takes the decision after both discriminators are inactive


#### Single Channel Analyzer

- Programmable lower level and window so that
  - the window can be moved through the whole range preserving the window size
- Build the upper level as lower level + window
- This is a primitive way to measure the amplitude spectrum of the pulses, but is simple! Normally the window position & width is optimized once and then the pulses are counted for long time

#### SCA – building blocks




#### SCA – put all together




# Discriminator – time over threshold (ToT)

- The idea is to measure roughly the amplitude of the pulses
- With a constant threshold, the time over the threshold is a function of the amplitude
- Provided the shape remains stable, the correlation ToT –
   Amplitude is non-linear but known




#### Discriminator – time over threshold



#### Discriminator – leading edge timing

- The same circuit can demonstrate another typical task in detector experiments – timing
- When measuring the time distance between two detector pulses, the simplest way to get a digital start and stop signals is to use a discriminator with constant threshold
- What is the problem of this solution?


#### Improving the leading edge timing



How to compensate for the "time walk"?

If the threshold is not constant, but depends on the signal amplitude... e.g. is just a constant fraction?

# Timing – leading edge vs. constant fraction



#### Solder your first board

P/Z & Shaping Amplifier

Constant Fraction Discriminator

All digital signals on a dual PMOD connector



2x 10..15V

on/off

Single Channel Analyzer

Thank you for your attention and patience!